



Reinforcement Bonding Point – One, Two or Four Hole Earth Point

Part No.	Hole Size (mm)	Size LxWxH (mm)
ESP00		65 x (φ) 50
ETP00	M10 x 20	70 x 35
EFP00		70 x 70

Connect reinforcement bar to earth point with stem diameter = 10.7mm or 70mm².

Re-Bar Bonding Point – 2 & 4 Hole Earth Point with Front Plate Cover

Part No.	Tape Size (mm)	Size LxWxH (mm)
ETC00	25 x 3	80 x 80
EFC00	25 x 3	80 x 80

Connect reinforcement bar to earth point with stem diameter = 10.7mm or 70mm² and supplied complete with front plate for connection of 25mmx3mm copper tape option with 70mmsq stranded copper wire cable.